

Box Instructions

<=Wrong Way

Right Way=>

Assembly

1. Push flaps inside the box, point tab to slot and insert.
2. Pull back inserted flaps to box side to interlock.
3. Fold side panel over.
4. Hold panel tight from inside, push snap fit in through slots.
5. Insert tab into respective slot.

Disassembly

1. Push snap fit back out.
2. Push both flaps inwards to disengage. Do NOT tear apart flaps to disassemble.

